

To prevent galling of stainless steel fasteners, liberally apply anti-seize compound to all bolt threads. Fasteners that have seized will not be warrantied.

- **1)** Install fender and core support brackets as pictured.
- **2)** Adjust rod ends as necessary to line up with mounting holes in brackets. Note that one end has standard right hand threads while the other has left hand threads.
- **3)** Tighten jam nuts against the fender brace rod.

