

Eddie Motorsports Billet Door Handles are designed to be used on several GM body styles. Some models require alteration of the shaft. Follow these instructions to check and, if necessary, modify the shaft for the correct fit with your application.

8. Insert the door handle with button and shaft installed until the shaft contacts the door lock. (Do not press hard.)
9. Measure the distance between where the shaft sticks out and where it should be to line up with the door properly.
10. Remove the portion of the shaft along with an extra $1/16^{\text{th}}$ of an inch to allow the button to fit properly.

Test handle assembly for functional operation.

